



CARE AND MAINTENANCE GUIDE



ATLAS
GLAZED ROOF SOLUTIONS

CARE AND MAINTENANCE GUIDE

POLYESTER POWDER COATED ALUMINIUM

DO

Wash regularly with a non-abrasive soft cloth or sponge using a solution of warm water containing a non-alkaline detergent (in a concentration which can be handled safely with bare hands).

When surfaces have been cleaned rinse thoroughly with clean water and dry off using a soft cloth.

DON'T

If atmosphere pollution has resulted in heavy soiling in no circumstances should an abrasive cleaner or cleaner containing ketones, esters or alcohol be used.

Where there is excessive staining then an approved renovating cream may be applied with a non-abrasive cloth.

*Note: do not get cream cleaners on self cleaning glass as they will damage the coating.

INDUSTRIAL ENVIRONMENT

The normal frequency of cleaning in an industrial setting should not be more than three monthly intervals.

URBAN ENVIRONMENT

The period between cleaning in urban environments can be extended to a maximum of 12 months.

PVCu SURFACES

DO

PVCu products need occasional cleaning with warm water and mild washing up liquid once every six months.

We would recommend a white cloth as colour dyes could stain the PVCu products.

PVCu products will be prone to dust up for approximately three months after installation.

This can be avoided by using PVCu cleaning agents that are available

DO NOT CLEAN WITH DRY CLOTH

MOVING PARTS AND GLAZING

MOVING PARTS

All opening sashes and rooflights have an opening device at the bottom, being either a spindle or electric actuator.

Moving parts and spindles should be oiled with machine oil at least once a year.

GLAZING

Coated self cleaning glass should not need regular cleaning, However, extended dry periods can cause a build up of contaminants on the coated surface, Under such circumstances, hose down the glass and let it dry naturally. Hosing down is best done in the coolest part of the day.

*Note: do not use pressure washers

Under no circumstances should metal objects or harsh chemical cleaners be used on the coated surface. Steel scrapers, steel wool, squeegees etc, will cause scratching and may lead to permanent damage of the coating.

*Note: Silicone should never be used in conjunction with self cleaning glass, Please always check that the sealants being used are self clean friendly.



WWW.ATLASROOFSOLUTIONS.CO.UK